

Oil pump replacement parts

(Oil fill cap, Strainer, Suction filter, Inlet check valve, Outlet check valve, Relief valve)

	Model	Part Number	Applicable pump
Oil fill cap	OC-1	549006	L3, L8
	OC-2	549005	EX, L20, ACM-II, AM, ADM
	OC-3	529432	MLZ, L5
	OC-4	529409	AMZ-III, AMZ100S, AMO-150S-III, AMO-II-150S, MMXL-III, MMX-II, AMR-III-150
Strainer	OS-1	521037	AMZ-III, AMZ100S, AMO-150S-III, AMO-II-150S, MMXL-III, MMX-II
Suction filter	SF-01	489001	AM, ADM
	SF-05	489005	L20, EX
	SF-07	489007	MLZ
	SF-08	489008	AMI-300S, AMI-1000S, AMI-300, AMI-1000
	SF-10	489010	MMXL-III
	SF-11	489011	AMZ-III, AMZ100S, AMO-150S-III, AMO-II-150S, AMR-III-150
	SF-12	489012	ACM-II
	SF-13	489013	MMX-II, L8
	SF-A	500324	AMS
	SF-L3	540727	L3
	SF-L5	540562	L5 · LK
Inlet check valve	IC-2.5	529008	MMX-II (2.5mℓ)
	IC-5.5	529009	MMX-II (5.5mℓ), L-8, L-20
	IC-EX	539001	MLZ, LK
Outlet check valve	OC-1	509001	MMX-II, EX, L-8, L-20
	OC-2	549070	MLZ, LK
Relief valve	RV-0.5	519003	AMI-300 <0.5MPa>
	RV-0.8	509002	AM, ACM, ADM, AMS <0.8MPa>
	RV-2.5	519002	AMI-100S, 200S, 300S, 1000S <2.5MPa>